Express5800/120Rg-2
System Release Notes

PN: 455-01716-000

Proprietary Notice and Liability Disclaimer

The information disclosed in this document, including all designs and related materials, is the valuable property of NEC Solutions (America), Inc. and/or its licensors. NEC Solutions (America), Inc. and/or its licensors, as appropriate, reserve all patent, copyright and other proprietary rights to this document, including all design, manufacturing, reproduction, use, and sales rights thereto, except to the extent said rights are expressly granted to others.

The NEC Solutions (America), Inc. product(s) discussed in this document are warranted in accordance with the terms of the Warranty Statement accompanying each product. However, actual performance of each product is dependent upon factors such as system configuration, customer data, and operator control. Since implementation by customers of each product may vary, the suitability of specific product configurations and applications must be determined by the customer and is not warranted by NEC Solutions (America), Inc.

To allow for design and specification improvements, the information in this document is subject to change at any time, without notice. Reproduction of this document or portions thereof without prior written approval of NEC Solutions (America), Inc. is prohibited.

Trademarks

Windows 2003 and Windows NT are registered trademarks of Microsoft Corporation.

SCO OpenServer is a trademark of Caldera Systems, Inc.

All other product, brand, or trade names used in this publication are the trademarks or registered trademarks of their respective trademark owners.

September 2004

Copyright 2004
NEC Solutions (America), Inc
10850 Gold Center Drive, Suite 200,
Rancho Cordova, CA 95670
All Rights Reserved

Express5800/120Rg-2
System Release Notes

The *Express5800/120Rg-2 System Release Notes* provide up-to-date information on your system. These notes also provide additional valuable information about your system that was not included in the user's guide.

Please read these notes in their entirety.

CONTENTS

Introduction 3
General Comments 3
Advisories 3
    EXPRESSBUILDER 3
Notices and Restrictions 4

Introduction

These System Release Notes cover the following topics:

- General Comments
- Advisories
- Notices and Restrictions

General Comments

The following general comments apply to this server.

- Versions of the Network Operating Systems tested and recommended are:

  — Windows® 2003

- Microsoft Windows® 2000 and NT© 4.0 are not supported.
- SCO OpenServer™ 5.06 is not supported.

Advisories

EXPRESSBUILDER

The following advisories apply to EXPRESSBUILDER.

- Windows 2003 must be installed using EXPRESSBUILDER Express Setup to take full advantage of NEC specific software for your server.

  Note: This advisory does not apply if your operating system was preloaded at the factory.

- If you already have an operating system installed when creating a maintenance partition, EXPRESSBUILDER will warn you of the existing partition. If you want to preserve the installed operating system, do not create the maintenance partition or the existing operating system will be overlaid by the maintenance partition.
- The Administrator Menu in the System Information Management segment of the Offline Maintenance Utility is accessible only by NEC authorized service representatives.
- EXPRESSBUILDER operates in floppy emulation mode. The emulated floppy drive portion of your system CD-ROM is designated Drive A and the remaining portion(s) of the CD-ROM is designated Drive Q. Your system diskette drive is Drive B. After creating the Off-line Maintenance Utility diskette, EXPRESSBUILDER prompts you to remove the diskette from Drive B. At this prompt, remove the diskette from your diskette drive.

Notices and Restrictions

Express5800/120Rg-2
Notices and Restrictions

This document describes the restrictions on Express5800/120Rg-2. Please read the list of notices below carefully to ensure that they are followed.

List of Notices

	Notices	Models
1	**Note when using Remote Management Card (N8115-01, N8115-02)** When using modem for Express Report Service, use serial port A. <supplement> When using serial port B (for example UPS), do the setting as below; In EXPRESSBUILDER menu, "System Management Function" ->"System Management Setting" ->"Configuration" ->"Change"->"Common" Set "Alert" and "Remote Control (WAN/Direct)" as "Disable". (Default setting is "Disable".)	120Rg-2
2	**Note for Seamless set up with SCSI HostRAID (On-Board RAID) Configuration** Installation procedure is as follows (1) When SCSI back up device is connected, take off cable connection. (2) Start "SCSI Select™ Utility" menu in POST, set the HostRAID function on both of SCSI A/B as "Enable", and do the installation. * Refer to the User's Guide for how to set the HostRAID function. (3) After finishing installation, connect back up device with cable. (4) Start "SCSI Select™ Utility" menu in POST, set the HostRAID function on the channel which is connected to the SCSI back up device as "disable". * Refer to the User's Guide for HostRAID setting.	
3	**Note when using HostRAID configuration on Windows 2000 Advanced Server + SP4 (if procured, installed, and supported by customer)** Memory capacity should be 6GB or less. (6GB is supported.)	
4	**Note when using LAN for Management** When using LAN for Management, for example Wake On LAN or the alert function via LAN using Remote Management Card, use LAN#1 port. LAN#2 port should not be used as LAN for management.	120Rg-2

If you have any questions about this document, please contact your sales representative.